




SPC

Collection



Luxury Flooring



What is SPC !

- > SPC (Stone Plastic Composite) is an engineered luxury vin that combines limestone and stabilizers to create an extremely durable core. SPC flooring is up to the task in both residential and commercial settings.
- > SPC Wooden flooring is the very much popular option for floors in use today. The pattern enables a plethora of colours and grains to be displayed side by side.
- > SPC flooring is very easy in installing as well. Any layment even can install the product. It comes with unique Uniclick technology. This glueless locking technology for flooring works perfectly for both the long and short sides of the flooring panel. In addition to that, Uniclic is a locking system that is suitable for all types of materials starting from 3.2 mm.
- > SPC flooring is constructed in a way as Engineered wood that gives it greater stability and resistance to changes in temperature and humidity.
- > The Good part is that it looks like hardwood flooring because the top floor is real, but all the underneath is an SPC rigid core which makes the product more better for commercial and residential uses.



Layers of Rigid Core Luxury Vinyl Flooring are :

- 1 - UV Coating
- 2 - Wear Layer
- 3 - Decore Film
- 4 - Rigid SPC Core
- 5 - Attached Underlayment


SPC Core

- > SPC flooring contains a solid, waterproof core that won't ripple or swell no matter how much liquid you subject it to..
- > The core is ultra-dense with no foaming agents. You'll find it in traditional WPC flooring. It gives you slightly less softness underfoot, Although it makes the flooring extra durable and long lasting.





I am
Easy Installation.



Uniclic Technology



> Uniclic was the first one-piece locking profile to be introduced to the market. Over the years it became the industry's favorite locking technology thanks to its unmatched production efficiency and technical performance.


There are many advantages of uniclick locking system that makes the product more easy and simple to use.

1. Uniclic is fast and simple
2. it has to be installed by an angular rotation movement.
3. can also be installed in a horizontal way by snapping the planks into each other.
4. no unwanted gaps or spaces between floorboards.
5. no height differences and a seamless joint
6. Uniclic profiles interlock very securely.
7. Ensured Long- Lasting Stability



SPC Flooring Installation







1. Adjust row so end cut is not less than 8".

2. Use shims to allow 3/8" expansion gap between the planks and the walls, or stationary interior room objects, so there is room for normal expansion and movement.

3. Starting from the LEFT with the tongue facing the wall, carefully place the first board in place.




4. Align the next piece by overlapping the short end of the first board. Engage the short end at a 45° angle of the tongue and groove. The board must be flat to engage completely. Tap lightly into place by using a rubber mallet and tapping block to firmly lock short end. Continue in this manner until reaching the final plank in the first row.




5. Cut the final board piece to length.


6. Begin the second row with the cut piece from the first row. If the cut piece is shorter than 8" (20cm), do not use it. Instead, begin with a new board to the left as necessary to align the edges of the end joint of the first row. Carefully push the board down until the tongue and groove lock together on the long side and ends.



7. Position the first board of the second row in place by angling it up slightly, pushing forward and interlocking the long side of the tongue. Slide the board to the left as necessary to align the edges of the end joint of the first row. Carefully push the board down until the tongue and groove lock together on the long side and ends.




8. Install second board of the second row (same as step 4 above). Slide close to the end joint without touching it. Ensure board lays flat.




BRIDGE

Attach a scrap piece of floor to bridge gap between ends of planks.




9. Tap firmly but gently on end joint with a rubber mallet and tapping block to fully engage short end. Before moving on the next board, ensure the end joints are flush and tight.



10. Install the remaining boards and rows in the same manner.

11. Cut the last board to size. If necessary, complete the tight fit by tapping the board into place with a pull bar.

12. Whenever practical, use cut pieces from previous rows as the starter board to reduce waste.
















>8in.

13. Maintain 8" spacing between end joints after the first rows for best appearance.

How to install the SPC Flooring?

- > 1. Adjust row so end cut is not less than 8".
- > 2. Use shims to allow 3/8" expansion gap between the planks and the walls, or stationary interior room objects, so there is room for normal expansion and movement.
- > 3. Starting from the LEFT with the tongue facing the wall, carefully place the first board in place.
- > 4. Align the next piece by overlapping the short end of the first board, Engage the short end at a 45° angle of the tongue and groove. The board must be flat to engage completely. Tap lightly into place by using a rubber mallet and tapping block to firmly lock short end. Continue in this manner until reaching the final plank in the first row.
- > 5. Cut the final board piece to length.
- > 6. Begin the second row with the cutpiece from the first row. If the cut piece is shorter than 8" (20cm), do not use it. Instead, begin with a new board to the left as necessary to align the edges of the end joint of the first row. Carefully push the board down until the gongue and groove lock together on the long side and ends.
- > 7. Position the first board of the second row in place by engling it up slightly, pushing forward and interlocking the long side of the tongue. Slide the board to the left as necessary to align the edges of the end joint of the first row. Carefully push the board down until the tongue and groove lock together on the long side and ends.
- > 8. Install second board of the second row (same as step 4 above). Slide close to the end joint without touching it. Ensure board lays flat. Attach a scrap piece of floor to bridge gap between ends of planks.
- > 9. Tap firmly but gently on end joint with a rubber mallet and tapping block to fully engage short end. Before moving on the next board, ensure the end joints are flush and tight.
- > 10. Install the remaining boards and rows in the same container.
- > 11. Cut the last board to size. If necessary, complete the tight fit by tapping the board into place with a pull bar.
- > 12. Whenever practical, use cut pieces from previous rows as the starter board to reduce waste.
- > 13. Maintain 8" spacing between end joints after the first rows for best apperance.

Advantages of SPC Vinyl Tiles

						
100% Waterproof	Termite proof	Stain Resistant	Anti slip	Pet friendly	Ecological	Easy to clean
						
Quick & Easy to install	Superior scratch resistance	Fire Resistant	Easy logistics	Recyclable	Reduce noise	

collection



QSW-421



QSW-426



QSW-431



QSW-436



QSW-441



QSW-446



QSW-451



QSW-456



QSW-461



QSW-466



QSW-422



QSW-427



QSW-432



QSW-437



QSW-442



QSW-447



QSW-452



QSW-457



QSW-462



QSW-467



QSW-423



QSW-428



QSW-433



QSW-438



QSW-443



QSW-448



QSW-453



QSW-458



QSW-463



QSW-468



QSW-424



QSW-429



QSW-434



QSW-439



QSW-444



QSW-449



QSW-454



QSW-459



QSW-464



QSW-469



QSW-425



QSW-430



QSW-435



QSW-440



QSW-445



QSW-450




QSW-455



QSW-460



QSW-465



QSW-470



THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 421 (SPANISH CEDAR)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 422 (WHITE LIMBA WOOD)








THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 423 (TIGER WOOD)








THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 425 (DEEP CHARCOAL)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 426 (BUTTERNUT)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 428 (MAPLE WOOD WHITE)





THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 429 (SLATE GREY)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 430 (GREYWOOD)








THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 431 (DARK WALNUT)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 434 (EBONY WOOD)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 435 (OAK WOOD GREY)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 436 (ANTIQUE PINE)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 438 (MAHOGANY WOOD)








THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 439 (CARBON GREY)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 440 (CARMEL BROWN)








THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 441 (CHESTNUT CHERRY)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 442 (BRUNETTE WOOD)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 443 (HONEY WOOD)









THICKNESS	:	5 + 1 = 6 MM
WEAR LAYER	:	0.5 MM
SIZE	:	305 X 610 MM
FINISH	:	MATT
INSTALLATION METHODS	:	UNILIN UNICLIC

QSW- 444 (COSMOS CARRARA)








THICKNESS	:	5 + 1 = 6 MM
WEAR LAYER	:	0.5 MM
SIZE	:	305 X 610 MM
FINISH	:	MATT
INSTALLATION METHODS	:	UNILIN UNICLIC

QSW- 445 (NEUTRAL GREY)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 446 (GLAMWOOD BEIGE)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 458(ROMANO OAKWOOD)







THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 460(TIMELESS OAK)






THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 471 (CHERRY MERLOT)






THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 472 (DRIFTWOOD HONEY)






THICKNESS	:	6 + 1 = 7 MM
WEAR LAYER	:	0.5 MM
SIZE	:	180 X 1220 MM
FINISH	:	MATT
INSTALLUTION METHOD	:	UNILIN UNICLIC

QSW- 473 (TUSCAN COFFEE)







TECHNICAL SPECIFICATION

Property	Test Method	Result
Dimensions	EN 427	1220*180mm
Thickness Over All	EN 428	3.0 mm, 4.0 mm, 5.0 mm, 7.0 mm
Thickness Wear Layer	EN 429	0.3 mm, 0.5 mm
Pell Strength of Layers	EN 431	Pass
Shear Forces of Layers	EN 432	Good
Residual Indentations	EN 433	Mean Value \leq 0.1mm
Dimension Stability	EN 434	Shrinkage \leq 0.12%/Curling \leq 1.2mm
Resistance to Chemicals	EN 423	Class 0
Castot Chair Continuous	EN 425	No Disturbance/No Delamination
Light Fastness	ISO 105 B02	\geq 6
ASTM E84-03	NFPA Class B1	
Slip Resistance	DIN 51130	R9

Specification

SPC core thickness	4 to 6 MM
Wear layer	0.3 AND 0.5 MM
Plank Size	180 X 1220 MM AND 228.6 X 1219.2 MM AND 228.6 X 1524 MM
Padding	IXPE Black 1.00 AND 1.50 MM
Material	100 % Virgin
Click Lock	Unilin Uniclic
Warranty	From 5 Years to 15 Years as per product specifications

M MADELEINE FLOORS



OFFICE ADDRESS :-



809-THE SPIRE, NEAR SHITAL PARK BRTS, 150 FEET RING ROAD, RAJKOT-360007, GUJARAT (INDIA).



FACTORY ADDRESS :-



SURVEY NO.92/P5-P1, 93-P1/P2/P4/P5, VILLAGE HARIPAR, BESIDES SAHKAR COTTON,
TANKARA-LATIPER HIGHWAY, TANKARA-360110, GUJARAT (INDIA).

